

AIRCO FOAM TREATMENT

AIRCONDITIONING CLEANER WITH ACTIVE FOAM

DISCRIPTION

Active foam for cleaning the air conditioning system in vehicles. Effectively cleans the evaporator (the source of contamination) and kills bacteria, yeasts and fungi. Leaves behind a neutral odor and provides a long-lasting protection against smells.

CHARACTERISTICS

- Provides fresh and clean air.
- Effectively removes musty smells.
- Actively kills and removes all health-threatening bacteria, yeasts and fungi.
- Forms a protective layer on the evaporator
- Safe treatment for humans and animals (CtgB approved under number (15565N))
- Can be carried out without the use of special equipment.
- Keeps windows free of condensation and prevents fogging.

INSTRUCTION MANUAL

- 1. Remove the pollen filter and/or activated carbon filter.
- 2. Open all air vents, including those intended for the rear passengers! Start the engine and let it idle.
- 3. Switch off the air conditioning pump.
- 4. Set the air conditioning system to the highest possible temperature.
- 5. Set the ventilation setting to maximum.
- 6. Turn on the recirculation mode.
- 7. Turn off the ignition after 5 minutes.
- 8. If necessary, disassemble the necessary parts to gain access to the evaporator.
- 9. Check that the condenser is dry.
- 10. Shake the can and mount the supplied hose/nozzle.
- 11. Bring the hose/nozzle to the evaporator and spray the entire contents of the can through the hose/nozzle onto the evaporator.
- 12. Allow the product to soak for 15 minutes.
- 13. Then open windows and doors and ventilate for \pm 15 minutes.
- 14. Mount all disassembled parts and install a new pollen filter/active carbon filter.
- 15. Run the fan for 5 minutes at its lowest setting.

TIPS

For optimal results, do not use the air conditioning for several hours.

After applying the foam, you can immediately check whether the drainage of the air conditioning works correctly and if it isn't blocked.

Clean the air conditioning at least twice a year.



RMC Lubricants B.V. Nikkelstraat 4, 6031 TR Nederweert, Nederland

T: +31 (0)495 54 42 16 | info@rmclubricants.com | www.rmclubricants.com

No rights can be granted to this article and in addition, we are not liable for inaccuracies, which may unexpectedly be mentioned in this article.

PERFORMANCE BY CLEANING



TECHNICAL INFORMATION

Basis: Propellant: Appearance: Spray pattern: Odor: Storage: Water, solvents, surfactants and biocide Propane-butane Stable white foam Stable white foam Neutral (10°C - 20°C) Store in a dry place.

Contents: 12 x 250 ml/carton (incl. hoses/nozzles)

 RMC Lubricants B.V.
 Nikkelstraat 4, 6031 TR Nederweert, Nederland

 T: +31 (0)495 54 42 16 | info@rmclubricants.com | www.rmclubricants.com

 No rights can be granted to this article and in addition, we are not liable for inaccuracies, which may unexpectedly be mentioned in this article.

